






# Flash Fire Motorized Blaster Alt 5 47010









1

5


1-4



1 - 5





6




1 - 6





















11







12





1 - 12







Did you install 3 AA (or LR6) batteries in the motor?



13



1 - 13





2  
1



1 - 16





**Once the clip is loaded and “clicks” in place, DO NOT PULL TRIGGER UNTIL TURNED ON!**

## **Tips and Troubleshooting**

### **If the motor is not working properly:**

- Check to see if you have fresh batteries and that they are installed correctly.
- Make sure the clip “clicks” into place or the motor won’t turn on.

- Check to see if dart is stuck in blaster.

- If it is still not working, call our Consumer Hotline at 1-800-KID-KNEX (USA and Canada only). See the back cover of the instructions book for other ways to contact K’NEX.

### **If a dart is stuck in the blaster:**

- Make sure the motor is turned off. Remove the clip and turn the model over. Carefully remove the dart by hand.

