




Flash Fire Motorized Blaster Alt 3 & Alt 4 47010










1 - 5

4

1




6




1 - 6


- 2  1 
- 1  1 
- 5  1 

7



1-7









- 1
- 2
- 3
- 5
- 3
- 3
- 1

10

1-9



1 - 10



Once the clip is loaded and “clicks” in place, DO NOT PULL TRIGGER UNTIL TURNED ON!

Tips and Troubleshooting

If the motor is not working properly:

- Check to see if you have fresh batteries and that they are installed correctly.
- Make sure the clip “clicks” into place or the motor won’t turn on.


- Check to see if dart is stuck in blaster.


- If it is still not working, call our Consumer Hotline at 1-800-KID-KNEX (USA and Canada only). See the back cover of the instructions book for other ways to contact K’NEX.

If a dart is stuck in the blaster:



- Make sure the motor is turned off. Remove the clip and turn the model over. Carefully remove the dart by hand.










2		3	
2			
4		2	
2			



- 2 
- 4 
- 2 
- 2 
- 12 
- 2 



4



1 - 3

6



1 - 4