





Flash Fire Motorized Blaster Alt 1 & Alt 2

47010










1

5

1-4


1-5





6


1-5















10




1 - 10









Did you install 3 AA (or LR6) batteries in the motor?






1 - 11



- 2 
- 1  2 
- 2 



1 - 13



**Once the clip is loaded and
“clicks” in place,
DO NOT PULL TRIGGER
UNTIL TURNED ON!**

Tips and Troubleshooting

If the motor is not working properly:

- Check to see if you have fresh batteries and that they are installed correctly.
- Make sure the clip “clicks” into place or the motor won’t turn on.


- Check to see if dart is stuck in blaster.

- If it is still not working, call our Consumer Hotline at 1-800-KID-KNEX (USA and Canada only). See the back cover of the instructions book for other ways to contact K’NEX.

If a dart is stuck in the blaster:


- Make sure the motor is turned off. Remove the clip and turn the model over. Carefully remove the dart by hand.







x2

1



1



2





2



- 2  4 
2 



3



1 - 3