





Flash Fire Motorized Blaster Alt 6 47010












- 3 
- 1  4 
- 1 


6






1 - 6



- 1 
- 6 
- 2 
- 6 
- 2 


7




1-7








11





1 - 10



1 - 11

13





1-13



14

1 - 13





1 - 14


15

- 1 
- 2 
- 2 
- 4 


1-14



1-15




- | | | | |
|---|---|---|---|
| 1 |  | 2 |  |
| 2 |  | 4 |  |





1 - 17

- 1
- 1
- 1
- 3
- 3
- 2
- 1


18




1 - 18



1 - 19







Did you install 3 AA (or LR6) batteries in the motor?



19

1 - 18



Once the clip is loaded and “clicks” in place, DO NOT PULL TRIGGER UNTIL TURNED ON!

Tips and Troubleshooting

If the motor is not working properly:

- Check to see if you have fresh batteries and that they are installed correctly.
- Make sure the clip “clicks” into place or the motor won’t turn on.

- Check to see if dart is stuck in blaster.

• If it is still not working, call our Consumer Hotline at 1-800-KID-KNEX (USA and Canada only). See the back cover of the instructions book for other ways to contact K’NEX.

If a dart is stuck in the blaster:

- Make sure the motor is turned off. Remove the clip and turn the model over. Carefully remove the dart by hand.

